

# INSTALLATION, OPERATING AND MAINTENANCE



**R410A**

CLOSE CONTROL UNIT

**INNOV@**  
ENERGY

**9 - 130 kW**

INNOVA ENERGY  
IOM-2205-E



[www.lennoxemea.com](http://www.lennoxemea.com)

**LENNOX**



## Index


<b>1</b>	<b>General Description</b>	<b>5</b>
1.1	Structure	7
1.2	Application limits	7
1.3	Cooling circuit	8
1.4	Installation warnings	13
<b>2</b>	<b>Inspection / Transport / Positioning</b>	<b>14</b>
2.1	Inspection on receipt	14
2.2	Lifting and transport	14
2.3	Unpacking	14
2.4	Positioning	14
2.5	Refrigerant connections	15
<b>3</b>	<b>Installation</b>	<b>16</b>
3.1	Service area	16
3.2	Dimensions	17
<b>4</b>	<b>Evacuation and Charging Operations</b>	<b>18</b>
4.1	Introductions	18
4.2	Full vacuum and charge of the unit	18
4.3	Evacuating a circuit “contaminated” with refrigerant	19
4.4	Charging positions (single point)	20
<b>5</b>	<b>Water properties</b>	<b>21</b>
<b>6</b>	<b>Humidifier</b>	<b>22</b>
<b>7</b>	<b>Electrical Connections</b>	<b>25</b>
7.1	Generalities	25
<b>8</b>	<b>Operating Diagrams</b>	<b>26</b>
<b>9</b>	<b>Start-Up</b>	<b>27</b>
9.1	Preliminary checks	27
9.2	Starting operations	27
9.3	Checks during operations	28
9.4	Checking the refrigerant charge	28
<b>10</b>	<b>Setting Operating Parameters</b>	<b>29</b>
10.1	Generalities	29
10.2	Maximum pressure switch	29
10.3	Minimum pressure switch	29
<b>11</b>	<b>Maintenance</b>	<b>30</b>
11.1	Warnings	30
11.2	Generalities	30
11.3	Air filter inspection	31
11.4	Set the right fan speed	34
<b>12</b>	<b>Troubleshooting</b>	<b>36</b>



# 1 General Description


ING CCAC self-contained units are specially designed for installation in technological environments such as Computer rooms, laboratories and in general where a high precision in climate control and a 24h/day operation are requested. ING units represent the state of the art between technology and design as well as all Lennox products: thanks to their characteristics, ING can be installed also in offices where people are working. The depth of 890 mm (600 mm for ING0091 and ING0131) for all versions, allows the compatibility with standard electronic devices: furthermore the innovative design and the high tech selected colours make ING units complementary to the last generation of IT devices. The internal design of the units in firstly made looking to efficiency and reliability but don't losing accessibility: **all** components, including e-heaters, fans, compressors, valves, etc. can be maintained from the front and furthermore the door(s) are dismountable in few seconds thanks to an innovative hinge: this is very important when units are installed in small corridors. The exclusive use of primary brands components and a fully integrated development process (CAD+CAM, CAE) stands for highest possible quality level regarding efficiency, reliability, maintenance time, pre and after sales support. All the units are available both in single circuit up to 80 kW and up to 110 kW in double circuit.

Fig. 1 Single circuit units



Rif.	Descrizione	Rif.	Descrizione
1	Filter	8	Liquid receiver
2	Microprocessor	9	Inverter
3	Ec Plug Fan	10	Umidifier
4	Electrical cabinet	11	Electrical heaters
5	BLDC scrol compressor	12	Condensate drain pan
6	Sight glass	13	Evaporator coil
7	Filter drier		

Fig. 2 Double circuit units



Rif.	Descrizione	Rif.	Descrizione
1	Filter	8	Liquid receiver
2	Microprocessor	9	Inverter
3	Ec Plug Fan	10	Umidifier
4	Electrical cabinet	11	Electrical heaters
5	BLDC scroll compressor	12	Condensate drain pan
6	Sight glass	13	Evaporator coil
7	Filter drier		

## 1.1 Structure

ING units are designed with a self supporting frame and all components are produced using sophisticated computer driven machines and special tools. All sheet metals are galvanized and all external panels are powder coated RAL 7016 giving to the units the image and the quality like last generation of IT devices. Units are completely closed and only frontal access is requested. Anyway it is also possible to have side access in order to reach the steam piping and the drain pan, or simply to substitute a damaged side panel: all this problems are very rare, but with ING units it is possible to solve them. The shape of the units is characterized with the curved edges with variable radium as for all HiRef products: this feature is obtained using special tools and gives both a good aesthetic and advantages against injuries. The compressor compartment is separated from the air flow and the special internal design allows the simple dismounting of the upper part of it ensuring an insuperable accessibility to all refrigerating components.

All fixing elements are made in stainless steel or in non corroding materials. The dry pan is made in stainless steel in order to ensure long time operation without damages.

All panels are thermally insulated with a polyurethane foam class 1 according UL 94 norms: this material, thanks to the open cells, gives good performances in sound absorption. As an option, sandwich panels are available: in this case mineral fibres are closed between the panel and a second sheet of metal giving the maximum in terms of internal cleaning. Double skin panels are classified between non flammable materials class A1 according DIN 4102 norms : the sound insulation is better than the standard solution, but the internal reflected sound power will increase the amount in delivery side (+2dB).


## 1.2 Application limits

Tab. 1 Operation limits  
*Power supply limits and storage conditions*

Model			ING . .
Power supply *			400 (±10%) / 3+N / 50
Storage conditions	Temperature	Min	-10 °C
		Max	+55 °C
	Relative humidity	Max	90 %

\* In case of different power supply see the electrical drawing attached.

Fig. 2 Application limits (DX unit with stadard condenser in catalog)



Applications with an external air temperature below 20°C, require a condensing control to ensure enough pressure drops through the expansion valve. Temperatures below -20° and down to -40°C require a flooding device in order to flood the condenser internal surface and get the right condensing T, even in case of strong and cold winds.

When unit working the heat load must not be less than 25% of the nominal cooling capacity of the unit. A lesser heat load can cause loss of control of room temperature and humidity, and frequently compressors power on and shutdown.

## 1.3 Cooling circuit

The entire refrigerating circuit is assembled in our production line including all pipe work and using only primary brand for components. The workers involved in the welding and pipe work process are qualified by a third part according CEE 97/23. **All air condensate units (ING A ./ ING D .) are precharged with nitrogen**

### Compressors

In ING units only primary brand scroll compressors in special execution for inverter application motor, are installed (excepted the 060 model in which a rolling piston compressor are installed) . Scroll compressor represent for CCAC units the best solution in terms of efficiency and reliability. The internal compression ratio is very close to the typical operating condition of CCAC giving the maximum in terms of COPs and the perfect balanced pressures at start up gives big advantages to the e\_motor in terms of reliability, mainly in this filed where frequent start up may be possible. All motors are thermally protected with an internal sensors chain: in case of overload this sensor opens without giving contacts to the connection box.

### Cooling components

- Molecular mesh activated-alumina filter dryer.
- Flow indicator with humidity indicator (indications are provided directly on the sight glass).
- High and low pressure switches.
- Schrader valves for checks and/or maintenance.

### Electric control board

Electric control board: The electric control board is constructed and wired in accordance with Directives 73/23/EEC and 89/336/EEC and related standards. The board may be accessed through a door after the main switch has been turned off. All the remote controls use 24 V signals powered by an insulating transformer situated on the electric control board.

- The mechanical safety devices such as the high pressure switched are of the kind that trigger directly; their efficiency will not be affected by any faults occurring in the microprocessor control circuit, in compliance with 97/23 PED.


### Microprocessor control

The microprocessor built into the unit allows the different operating parameters to be controlled from a set of pushbuttons situated on the electric control board:

- Switching On/Off of compressor(s) to maintain the temperature set point T inside the shelter.
- Alarm management :
  - High / Low pressure;
  - Dirty filters alarm (optional);
  - Air flow alarm.
- Alarm signalling.
- Display of operating parameters.
- RS232, RS485 serial output management (optional).
- Phase sequence error (not displayed by the mP, but prevents the compressor from starting up) (only DX).


**See microprocessor control manual for further details, also in relation to particular customer specifications.**

Fig. 3 Basic cooling circuit DX version (1 inverter circuit)




Pos.	Description	Pos.	Description
1	Compressor	9	LP pressure switch
2	HP pressure switch	10	Liquid receiver
3	Pressure transmitter (Opt.)	11	Condenser coil
4	Ball valve	12	Flooding valve
5	Refrigerant filter	13	Safety valve
6	Sight glass	14	Check valve
7	Thermostatic valve	15	Solenoid valve
8	Evaporating coil	16	Oil Separator

Fig. 4 Basic cooling circuit DX version (2 inverter circuits)




Pos.	Description	Pos.	Description
1	Compressor	9	LP pressure switch
2	HP pressure switch	10	Liquid receiver
3	Pressure transmitter (Opt.)	11	Condenser coil
4	Ball valve	12	Flooding valve
5	Refrigerant filter	13	Safety valve
6	Sight glass	14	Check valve
7	Thermostatic valve	15	Solenoid valve
8	Evaporating coil	17	Oil Separator

Fig. 5 Basic cooling circuit DX version (1 On-Off circuit + 1 inverter circuit)



Pos.	Descrizione	Pos.	Descrizione
1	Compressor	9	LP pressure switch
2	HP pressure switch	10	Liquid receiver
3	Pressure transmitter (Opt.)	11	Condenser coil
4	Ball valve	12	Flooding valve
5	Refrigerant filter	13	Safety valve
6	Sight glass	14	Check valve
7	Thermostatic valve	15	Solenoid valve
8	Evaporating coil	18	Oil Separator

Fig. 6 Basic cooling circuit DX version (1 On-Off tandem circuit + 1 inverter circuit)



Pos.	Descrizione	Pos.	Descrizione
1	Compressor	10	LP pressure switch
2	HP pressure switch	11	Liquid receiver
3	Pressure transmitter (Opt.)	12	Condenser coil
4	Ball valve	13	Flooding valve
5	Refrigerant filter	14	Safety valve
6	Sight glass	15	Check valve
7	Thermostatic valve	17	Bypass valve
8	Evaporating coil	18	Oil Separator
9	LP pressure switch		

## 1.4 Installation warnings

### General rules

- When installing or servicing the unit, you must strictly follow the rules provided in this manual, comply with the directions on the units themselves and take all such precautions as are necessary.
- The fluids under pressure in the cooling circuit and the presence of electrical components may cause hazardous situations during installation and maintenance work.



**All work on the unit must be carried out by qualified personnel only, trained to do their job in accordance with current laws and regulations.**

- Failure to comply with the rules provided in this manual or any modification made to the unit without prior authorisation will result in the immediate invalidation of the warranty.



**Warning: Before performing any kind of work on the unit, make sure it has been disconnected from the power supply.**

## 2 Inspection / Transport / Positioning

### 2.1 Inspection on receipt

On receiving the unit, check that it is perfectly intact: the unit left the factory in perfect conditions; immediately report any signs of damage to the carrier and note them on the "Delivery Slip" before signing it.

**Lennox** or its agent must be promptly notified of the entity of the damage. The Customer must submit a written report describing every significant sign of damage.

### 2.2 Lifting and transport

While the unit is being unloaded and positioned, utmost care must be taken to avoid abrupt or violent manoeuvres. The unit must be handled carefully and gently; avoid using machine components as anchorages or holds and always keep it in an upright position.

The unit should be lifted using the pallet it is packed on; a transpallet or similar conveyance means should be used.



**Warning: in all lifting operations make sure that the unit is securely anchored in order to prevent accidental falling or overturning.**

### 2.3 Unpacking

The packing must be carefully removed to avoid the risk of damaging the unit. Different packing materials are used: wood, cardboard, nylon etc. It is recommended to keep them separately and deliver them to suitable waste disposal or recycling facilities in order to minimise their environmental impact.

### 2.4 Positioning

Bear in mind the following aspects when choosing the best site for installing the unit and the relative connections:

- positioning and dimensions of the coupling flanges and refrigerant connections;
- location of power supply;
- solidity of the supporting floor.

It is recommended to first prepare holes in the floor/wall for passing through the power cables and for the air outlet (down flow units).



## 2.5 Refrigerant connections

Rotalock valves are tightly closed by means of closing plugs mounted on dedicated taps holding a P.T.F.E. Teflonring. Rotalock valves provided with “ODS” exitjunction have to be welded to tubes by means of brazing with a maximum fusion temperature of 850° C. It is necessary to protect the valve and/or adapter housing from the flame by means of a dedicated guard.

The tightening torque for nuts to be mounted on rotating fittings are:

- Rtk. Ch. 22 (3/4" – 16 UNF): 20÷30 Nm
- Rtk. Ch. 30 (1" –14 UNS): 50÷85 Nm
- Rtk. Ch. 36 (1" ¼ - 12 UNF): 70÷105 Nm
- Rtk. Ch. 50 (1" ¾ - 12 UN): 100÷150 Nm
- Rtk. Ch. 65 (2" ¼ - 12 UN): 150÷200 Nm

Refer to unit dimensional drawing for rotalock dimension.




### 3 Installation

#### 3.1 Service area

The **ING** air-conditioning unit is suitable for all environments except aggressive ones. Do not place any obstacles near the units and make sure that the air flow is not impeded by obstacles and/or situations causing back suction.

Fig. 7 Service area



Model	A(mm)	B(mm)	C(mm)	D(mm)	E(mm)
ING0091	600	650	600	10	1875
ING0131	900	650	600	10	1875
ING0201	1010	750	890	10	1998
ING0251	1010	750	890	10	1998
ING0301	1270	750	890	10	1998
ING0381	1270	750	890	10	1998
ING0441	1270	750	890	10	1998
ING0501	1760	750	890	10	1998
ING0551	1760	750	890	10	1998
ING0641	2030	750	890	10	1998
ING0701	2030	750	890	10	1998
ING0801	2510	750	890	10	1998
ING0852	2510	750	890	10	1998
ING0962	2510	750	890	10	1998
ING1003	2510	750	890	10	1998
ING1103	2510	750	890	10	1988


The following steps should be carried out to ensure proper installation:

- Apply a anti-vibration rubber lining between the unit and the bottom.
- Position the unit on the floor / floorstand (base frame).

The recommended sizes for the power cables and emergency line are shown in the related electrical drawings.

In case of units equipped with plenum or base module it is necessary apply a gasket between the unit and accessory to ensure the air-tight.

### 3.2 Dimensions



Modello	A(mm)	B(mm)	C(mm)
ING0091	1875	600	600
ING0131	1875	900	600
ING0201	1998	1010	890
ING0251	1998	1010	890
ING0301	1998	1270	890
ING0381	1998	1270	890
ING0441	1998	1270	890
ING0501	1998	1760	890
ING0551	1998	1760	890
ING0641	1998	2030	890
ING0701	1998	2030	890
ING0801	1998	2510	890
ING0852	1998	2510	890
ING0962	1998	2510	890
ING1003	1998	2510	890
ING1103	1988	2510	890

## 4 Evacuation and Charging Operations




This type of work must be carried out by qualified personnel only trained to do their job in accordance with current laws and regulations.

### 4.1 Introductions

The contemporaneous presence of liquid and vapour requires for both to be in a state of saturation (Gibb's law), as shown in Fig. 8. In thermal equilibrated conditions, the pressure in the tank corresponds to the ambient temperature. Withdrawal of refrigerant from the tank has following effects:

- ... withdrawal of refrigerant charge: pressure drop inside the tank.
- ... pressure drop inside the tank: T drop & change of status.
- ... T drop & change of status: evaporation of part of the liquid, causing a cooling down of the liquid.
- ... cooling of liquid: thermal exchange with ambient air, further evaporation of remaining liquid; the original pressure in the tank will be restored after a certain period of time.

Fig. 8 Gibb's law diagram



### 4.2 Full vacuum and charge of the unit

#### Vacuum cycle


#### Air condensate units (ING A. / ING D.) precharge with nitrogen

After the execution of the refrigerant copper line between the indoor unit and the remote condenser, proceed with the vacuum operation connecting the pump to the unit rotalock connection. Please make sure to do not open them in order to keep the refrigerant inside the unit and do the vacuum only in the refrigerant line and inside the remote condenser.

In order to obtain a satisfactory result it is necessary to connect the vacuum pump to the pressure taps of both rotalock connections.

In general it is better to apply a "long" rather than a "hard" vacuum: reaching a low pressure too abruptly may in fact cause that any remaining humidity evaporates instantaneously, thus freezing part of it.

Fig. 9 Vacuum cycle diagram




The figure Fig. 9 represents a vacuum cycle and an optimal subsequent pressure rise for the refrigeration devices we manufacture. Generally in bigger refrigeration systems or if there is a suspicion of an extensive quantity of humidity in the refrigeration circuit, the vacuum needs to be “broken” by using anhydrous nitrogen. Then the steps of evacuation need to be repeated as described before. This operation facilitates the removal of remaining and/or frozen humidity during the evacuation process.

### 4.3 Evacuating a circuit “contaminated” with refrigerant

The first step is to remove the refrigerant from the circuit. To do this a specific machine is necessary with a drying compressor in order to recover the refrigerant. All refrigerants all tend to be dissolve the in oil in the compressor sump). The “Oil” Fig. 10 illustrates a specific property (Charles’ Law) of gases, which are more soluble in liquids as the pressure increases but less soluble as the temperature increases.

Fig. 10 Charles’ law diagram



If the oil in the sump is held at a constant pressure, an increase in temperature will significantly reduce the amount of refrigerant dissolved in it, thus ensuring that the lubricating function desired is maintained. The problem of inadequate lubrication occurs if the crankcase is not duly heated, above all after seasonal interruptions when, due to the suction effect of the compressor, there is an abrupt drop in pressure inside the sump, which results in considerable evaporation of the refrigerant previously dissolved in the oil. If heating elements were not installed, this phenomenon would cause two problems:

- 1 ) The release of refrigerant from the cooling circuit tends to cool down the oil and thus actually creates the opposite effect by keeping more refrigerant dissolved in the oil: for this reason, it is advisable to switch on the crankcase heater during the evacuation process.

- 2) If a high % of refrigerant gets in contact with the Pirani gauge (vacuum sensor), it may “mislead” this sensitive sensor and misinterpret the value for a certain period of time. For this reason (if no machine for recovering refrigerant is available) it is nonetheless advisable to switch on the crankcase heater and to avoid full vacuum before the circuit has been adequately purged of refrigerant. The refrigerant may in fact dissolve in the oil of the vacuum pump, reducing its performance for a long time (hours).

#### **4.4 Charging positions (single point)**

The best position to charge the unit is the section between the thermostatic valve and the evaporator. Take care to avoid the fixing of the thermostat bulb until the operation is completed. It is important to ensure that the valve orifice remains open in order to allow the passage of refrigerant also towards the condenser / liquid receiver.

If possible, avoid the charge of refrigerant into the suction line of the compressor as this may cause excessive dilution of the lubricant.

In case of air cooled units, in the attached “Piping Design Criteria” is described how to calculate the estimate refrigerant charge.

## 5 Water properties

The quality and chemical composition of the cooling and heat transfer medium have a great influence on the Lifetime and on heat transfer and thus on the performance of the specific unit.

Basically, avoid all types of floating matter in the cooling and heat transfer medium.

When the suspended matter accumulates in the heat exchanger the heat transfer and thus the performance of the unit deteriorate.

Below are the values of the dissolved substances and the water properties recommended by the manufacturer listed.


The information refers to the use of exchangers made of copper.

If the concentration of some components will be out of range, the customer has to introduce a correction, otherwise the system will be out of warranty.

WATER CONTENT	CONCENTRATION
Alkalinity (HCO <sub>3</sub> <sup>-</sup> )	70 - 300 ppm
Sulphate (SO <sub>4</sub> <sup>2-</sup> )	< 70 ppm
HCO <sub>3</sub> <sup>-</sup> / SO <sub>4</sub> <sup>2-</sup>	> 1.0 ppm
Electrical conductivity	10 - 500 µS/cm
pH*	7.5 - 9.0
Ammonium (NH <sub>4</sub> <sup>+</sup> )	< 2 ppm
Chloride (Cl <sup>-</sup> )	< 30 ppm
Free chlorine (Cl <sub>2</sub> )	< 0.5 ppm
Hydrogen sulphide (H <sub>2</sub> S)	< 0.05 ppm
Carbon dioxide (CO <sub>2</sub> )	< 5 ppm
Total hardness (°dH)	4.5 - 8.5
Nitrate (NO <sub>3</sub> <sup>-</sup> )	< 100 ppm
Iron (Fe)**	< 0.2 ppm
Aluminium (Al)	< 0.2 ppm
Manganese (Mn)**	< 0.05 ppm
Calcium carbonate (CaCO <sub>3</sub> )	< 200 ppm
Phosphate (PO <sub>4</sub> <sup>3-</sup> )	< 2 ppm
Ammonia (NH <sub>3</sub> )	< 0.5 ppm
Temperature (°C)	< 65 °C
Oxygen content	< 0.1 ppm
*Generally a low pH value (less than 6) increases the risk of corrosion and a high pH (above 7.5) decreases the risk of corrosion **Fe <sup>3+</sup> and Mn <sup>4+</sup> are powerful oxidants and may increase the risk of localized corrosion on stainless steel	

## 6 Humidifier

The installation of the humidifier requires the connection to the water supply and drain hoses.



To simplify installation, it is recommended to use hose with an inside diameter of 6 mm and an outside diameter of 8 mm and the revolving 3/4" G connection, either straight or 90°.

**A shut-off tap and a mechanical filter should be installed to trap any solid impurities.**

The drain water is connected using a section of rubber or plastic hose resistant to 100°C, with a recommended inside diameter of 32 mm.

The drain connector is suitable for heat sealing with polypropylene drain pipes.

**IMPORTANT WARNING: the drain hose must be free, without backpressure and with a drain trap immediately downstream of the connection to the humidifier.**

The following conditions represent correct water connection:

- installation of a shut-off tap in the supply water line;
- presence of a mechanical filter in the supply water line;
- water temperature and pressure within the allowed values;
- drain hose resistant to temperatures of 100°C;
- minimum inside diameter of the drain hose of 25 mm

- minimum slope of the drain hose greater than or equal to 5°;
- electrically **non-conductive** sleeve.
- presence of a drain trap in the drain hose

**IMPORTANT WARNING: when installation is completed, flush the supply hose for around 30 minutes by piping the water directly into the drain without sending it into the humidifier. This will eliminate any scale or processing residues that may block the fill valve or cause foam when boiling.**

### **SUPPLY WATER**

The humidifier must be supplied with mains water, with the following characteristics:

- pressure between 0.1 and 0.8 MPa (1 to 8 bar, 14.5 to 116 psi);
- temperature between 1 and 40°C;
- instant flow rate not lower than the rated fill solenoid valve flow rate (0.6 l/min)
- connection type 3/4" G male.

### LIMIT VALUES FOR THE SUPPLY WATER WITH MEDIUM-HIGH CONDUCTIVITY IN AN IMMERSSED ELECTRODE HUMIDIFIER

	Symbol	Unit	Min	Max
Hydrogen ions	pH		7	8.5
Specific conductivity at 20°C	$\sigma_R, 20^\circ\text{C}$	$\mu\text{S/cm}$	300	1250
Total dissolved solids	TDS	mg/l	(1)	(1)
Dry residue at 180°C	R <sub>180</sub>	mg/l	(1)	(1)
Total hardness	TH	mg/l CaCO <sub>3</sub>	100(2)	400
Temporary hardness		mg/l CaCO <sub>3</sub>	60(3)	300
Iron + Manganese		mg/l Fe + Mn	0	0.2
Chlorides		ppm Cl	0	30
Silica		mg/l SiO <sub>2</sub>	0	20
Residual chlorine		mg/l Cl <sup>-</sup>	0	0.2
Calcium sulphate		mg/l CaSO <sub>4</sub>	0	100
Metallic impurities		mg/l	0	0
Solvents, diluents, soaps, lubricants		mg/l	0	0

(1) Values depending on specific conductivity; in general: TDS  $\cong$  0.93 \*  $\sigma_{20}$ ; R<sub>180</sub>  $\cong$  0.65 \*  $\sigma_{20}$

(2) Not lower than 200% of the chloride content in mg/l of Cl<sup>-</sup>

(3) Not lower than 300% of the chloride content in mg/l of Cl<sup>-</sup>

### LIMIT VALUES FOR THE SUPPLY WATER WITH MEDIUM-LOW CONDUCTIVITY IN AN IMMERSSED ELECTRODE HUMIDIFIER

	Symbol	Unit	Min	Max
Hydrogen ions	pH		7	8.5
Specific conductivity at 20°C	$\sigma_R, 20^\circ\text{C}$	$\mu\text{S/cm}$	125	500
Total dissolved solids	TDS	mg/l	(1)	(1)
Dry residue at 180°C	R <sub>180</sub>	mg/l	(1)	(1)
Total hardness	TH	mg/l CaCO <sub>3</sub>	50(2)	250
Temporary hardness		mg/l CaCO <sub>3</sub>	30(3)	150

Iron + Manganese	mg/l Fe + Mn	0	0.2
Chlorides	ppm Cl	0	20
Silica	mg/l SiO <sub>2</sub>	0	20
Residual chlorine	mg/l Cl <sup>-</sup>	0	0.2
Calcium sulphate	mg/l CaSO <sub>4</sub>	0	60
Metallic impurities	mg/l	0	0
Solvents, diluents, soaps, lubricants	mg/l	0	0

(1) Values depending on specific conductivity; in general:  $TDS \cong 0.93 * \sigma_{20}$ ;  $R_{180} \cong 0.65 * \sigma_{20}$

(2) Not lower than 200% of the chloride content in mg/l of Cl<sup>-</sup>

(3) Not lower than 300% of the chloride content in mg/l of Cl<sup>-</sup>

**Warning:** no relation can be demonstrated between water hardness and conductivity.

**IMPORTANT WARNING: do not treat water with softeners!** This could cause corrosion of the electrodes or the formation of foam, leading to potential operating problems or failures.

**Avoid:**

- using well water, industrial water or water drawn from cooling circuits; in general, avoid using potentially contaminated water, either from a chemical or bacteriological point of view;
- adding disinfectants or corrosion inhibitors to water, as these substances are potentially irritant.

**DRAIN WATER**

Inside the humidifier the water boils and is transformed into steam, without the addition of any substances. The drain water, as a result, contains the same substances that are dissolved in the supply water, yet in greater quantities, depending on the concentration in the supply water and the set draining cycles, and **may reach temperatures of 100°C**. Not being toxic, it may be drained into the sewage system. The drain connector has an external diameter of 32 mm.

## 7 Electrical Connections

### 7.1 Generalities



**Before carrying out any job on electrical parts, make sure the power supply is disconnected**

Check that the mains electricity supply is compatible with the specifications (voltage, number of phases, frequency) shown on the unit rating plate. The power connection for single-phase loads is to be made with a three-pole cable and “N” wire at the centre of the star (optional: power supply w/o neutral).



**The size of the cable and line protections must conform to the specifications provided in the wiring diagram (attached to the documentation of the unit).**

The supply voltage may not undergo fluctuations exceeding  $\pm 10\%$  and the unbalance between phases must always be below 2%.



**The above operating conditions must always be complied with: failure to ensure said conditions will result in the immediate invalidation of the warranty.**

The electrical connections must be made in accordance with the information shown in the wiring diagram provided with the unit and with current and local regulations. An earth connection is **mandatory**. The installer must connect the earthing wire using the earthing terminal situated on the electric control board (yellow and green wire). The power supply to the control circuit is taken from the power line through an insulating transformer situated on the electric control board.

The control circuit is protected by suitable fuses or automatic breakers depending on the unit size.



**When the motor runs independently due to air flowing through or if it continues to run down after being turned off, dangerous voltages of over 50V can arise on the motor internal connections through operation of the generator.**




**Even after disconnecting the mains voltage, life-threatening charges can appear between the protective ground “PE” and the mains connection. The protective earth is conducting high discharge currents (dependent on the switching frequency, current source voltage and motor capacity). Earthing in compliance with EN specifications shall therefore be observed even for testing and trial conditions (EN 50 178, Art.5.2.11).**

Regarding the differential protection that needs to be installed upstream, it is necessary to use a type A switch that is sensitive to direct currents. It is mandatory for it to have the following features:


1. Calibratable operation threshold
2. Calibratable operation delay

## 8 Operating Diagrams


**DOWNFLOW**



**UPFLOW**



**DISPLACEMENT**



## 9 Start-Up

### 9.1 Preliminary checks


- Check that the electrical connections have been made properly and that all the terminals **are securely tightened**. This check should also be included in a periodic six-month inspection.
- Check that the voltage at the RST terminals is  $400\text{ V} \pm 10\%$  and make sure the yellow indicator light of the phase sequence relay is on (only DX versions). The phase sequence relay is positioned on the electric control board; if the sequence is not duly observed, it will not enable the machine to start.
- Make sure there are no refrigerant leakage that may have been caused by accidental impacts during transport and/or installation (monobloc unit).
- Check the power supply to the crankcase heater, where present



**The heating elements must be turned on at least 12 hours before the unit is started. They are automatically activated when the main switch is put on. Their function is to raise the T of the oil in the sump and limit the quantity of refrigerant dissolved in it.**

To verify whether the heating elements are working properly, check the lower part of the compressors: it should be warm or in any case at a temperature 10 - 15 °C higher than the ambient temperature.

Fig. 12 Charles' law diagram



The diagram above illustrates a specific property of gases (Charles' Law), which are more soluble in liquids as the pressure increases but less soluble as the temperature increases: if the oil in the sump is held at a constant pressure, an increase in temperature will significantly reduce the amount of refrigerant dissolved in it, thus ensuring that the desired lubricating function is maintained.

### 9.2 Starting operations

Before starting the unit, turn the main switch on, select the operating mode desired from the control panel and press the "ON" button on the control panel.

**If the unit fails to start up, check if the service thermostat has been set according to the nominal values provided.**



**You should not disconnect the unit from the power supply during periods when it is inoperative but only when it is to be taken out of service for a prolonged period (e.g. at the end of the season).**

### 9.3 Checks during operations

Check the phase sequence relay (only DX versions) on the control board to verify whether the phases occur in the correct sequence: if they do not, disconnect the unit from power supply and invert two phases of the incoming three-pole cable. Never attempt to modify internal electrical connections: any undue modifications will immediately invalidate the warranty.

### 9.4 Checking the refrigerant charge

- After a few hours of operation, check whether the liquid level indicator has a green ring: a yellow colour indicates the presence of humidity in the circuit. In such a case the circuit must be dehumidified by qualified personnel.
- Large quantities of bubbles should not appear through the liquid level indicator. A constant passage of numerous bubbles may indicate that the refrigerant level is low and needs to be topped up.
- Make sure the overheating of the cooling fluid is limited to between 5 and 8 °C: to this end:
  - 1 ) read the temperature indicated by a contact thermometer placed on the compressor suction pipe;
  - 2 ) read the temperature indicated on the scale of a pressure gauge connected to the suction pipe of the compressor; refer to the pressure gauge scale for the refrigerant R410A.

The degree of overheating is given by the difference between the temperatures thus determined.

- Make sure that the Sub-cooling of the cooling fluid is limited to between 3 and 5°C; to this end:
  - 1 ) read the temperature indicated by a contact thermometer placed on the condenser outlet pipe;
  - 2 ) read the temperature indicated on the scale of a pressure gauge connected to the liquid inlet at the condenser outlet; refer to the pressure gauge scale for the refrigerant R410A.

The degree of Sub-cooling is given by the difference between the temperatures thus determined.



**Warning: ING units are design for R410A refrigerant.**  
**Any top-ups must be made using the same type of refrigerant. This operation is to be considered extraordinary maintenance work and must be performed by qualified personnel only**



**Warning: The refrigerant R410A requires “POE” polyolester oil of the type and viscosity indicated on the compressor rating plate. For no reason should oil of a different type be introduced into the oil circuit.**



**Warning: The air condensate units (ING\_A . / ING\_D .) are Factory pre-charge with nitrogen**

## 10 Setting Operating Parameters

### 10.1 Generalities

All the control devices are set and tested in the factory before the unit is dispatched. However, after the unit has been in service for a reasonable period of time you can perform a check on the operating and safety devices.

The settings are shown in Tab. 5 e Tab. 6.



**All servicing of the equipment is to be considered extraordinary maintenance and may be carried out BY QUALIFIED TECHNICIANS ONLY: incorrect settings may cause serious damage to the unit and injuries to persons.**

The operating parameters and control system settings configurable by means of the microprocessor control are password protected if they have a potential impact on the integrity of the unit.

Tab. 5 Setting of control devices

Control device		Set point	Differential
Differential air pressure switch (air flow)	Pa	50	20
Differential air pressure switch (dirty filter)	Pa	350	20

*Values to be calibrated depending on the application.*

Tab. 6 Setting of control and safety devices

Control device		Activation	Differential	Resetting
Maximum pressure switch	Bar-g	40.5	1.0	Manual
Minimum pressure switch	Bar-g	2.0	1.0	Automatic
Modul. condensation control devices (DX versions)	Bar-g	22.0	10.0	
Time lapse between two compressor starts	s	360	-	-

### 10.2 Maximum pressure switch

The high pressure switch stops the compressor when the outlet pressure exceeds the set value.



**Warning: do not attempt to change the setting of the maximum pressure switch: Should the latter fail to trip in the event of a pressure increase, the pressure relief valve will open.**

The high pressure switch must be manually reset; this is possible only when the pressure falls below the differential set (see Table 6).

### 10.3 Minimum pressure switch

The low pressure switch stops the compressor when the inlet pressure falls below the set value for more than 1 second.

The switch is automatically reset when the pressure rises above the set differential (see Table 6).

## 11 Maintenance

The only operations to be performed by the user are to switch the unit on and off. All other operations are to be considered maintenance work and must thus be carried out by qualified personnel trained to do their job in accordance with current laws and regulations.

### 11.1 Warnings



**All the operations described in this chapter MUST ALWAYS BE PERFORMED BY QUALIFIED PERSONNEL ONLY.**



**Before carrying out any work on the unit or accessing internal parts, make sure you have disconnected it from the mains electricity supply.**



**The upper part and the outlet pipe of the compressor reach high temperatures. Be especially careful when working in the surrounding area with the panels off.**



**Be especially careful when working in proximity to finned coils since the 0.11 mm-thick aluminum fins can cause superficial injuries due to cuts.**



**After completing maintenance jobs, always replace the panels enclosing the units and secure them with the fastening screws provided.**

### 11.2 Generalities

To guarantee a constantly satisfactory performance over time, it is advisable to carry out routine maintenance and checks as described below. The indications below are related to standard tear and wear.

Tab. 7 Routine maintenance



Operation	Frequency
Check the efficiency of all the control and safety devices.	Once a year
Check the terminals on the electric control board and compressor terminal boards to ensure that they are securely tightened. The movable and fixed contacts of the circuit breakers must be periodically cleaned and replaced whenever they show signs of deterioration.	Once a year
Check the refrigerant level by means of the liquid level indicator.	Every 6 months
Check the efficiency of the differential air pressure switch and dirty filter differential pressure switch (option).	Every 6 months
Check the condition of the air filter and replace it if necessary.	Every 6 months
Check the humidity indicator (green = dry, yellow = humid) on the liquid level indicator; if the indicator is not green as shown on the indicator sticker (see pag.20).	Every 6 months
Check the refrigerant charge (see page 20).	Every 6 months

### 11.3 Air filter inspection

Fig. 13 Inspecting the air filter

➤ **Model ING 0091/0131**


- Open the frontal panel to have access to the filter vane.
- Pull out the filter
- Check the filter status and change if it's necessary.



Model ING 0201/0251/0301/0381/0441/0501/0551/0641/0701/0801/0852/0962/1003/1103

### DOWNFLOW UNITS


- Open the frontal panel to have access to the filter vane.
- Pull out the filter
- Check the filter status and change if it's necessary.



Model ING 0201/0251/0301/0381/0441/0501/0551/0641/0701/0801/0852/0962/1003/1103


### UPFLOW UNITS

- Open the frontal panel to have access to the filter vane.
- Remove the fixing screw and the metal support.
- Pull out the filter from the right side.
- Proceed with the second filter like the first one.



## 11.4 Set the right fan speed

The adopted fans are of the backward curved blades type in combination with a 4 poles e-motor. This kind of fan has very high performances so that it's speed has to be reduced in order to match to the nominal air flow with the real external pressure drops: in case of wrong selection, the air flow may exceed the limits with possible water dragging out from the coils (down flow units) or in case of DX units. a not sufficient airflow can cause ice on the coil.



The fan speed has to be selected according to the enclosed table.

In the EC fans the rotation speeds are selected with different values of the control tension (0 - 10V). If in the unit is present the advanced control the right value of the control tension is set by the keyboard present in the advanced control.

## 11.5 Repairing the cooling circuit



**While performing repairs on the cooling circuit or maintenance work on the compressors, make sure the circuit is left open for as less time as possible. Even if briefly exposed to air, ester oils tend to absorb large amounts of humidity, which results in the formation of weak acids.**

If the cooling circuit has undergone any repairs, the following operations must be carried out:

- tightness test;
- evacuation and drying of the cooling circuit;
- charging with refrigerant.



**If the system has to be drained, always recover the refrigerant present in the circuit using suitable equipment; the refrigerant should be handled exclusively in the liquid phase.**

## 11.6 Tightness test

Fill the circuit with anhydrous nitrogen supplied from a tank with a pressure-reducing valve until the pressure rises to 22 bars.



**During the pressurization phase, do not exceed a pressure of 22 bars on the compressor low pressure side.**

The presence of any leaks must be determined using special leak detectors. Should any leaks be detected during the test, empty out the circuit before repairing the leaks with suitable alloys.



**Do not use oxygen in the place of nitrogen as a test agent, since this would cause a risk of explosion.**

### 11.7 Hard vacuum and drying of cooling circuit

To achieve a hard vacuum in the cooling circuit it is necessary to use a pump capable of generating a high degree of vacuum, i.e. 150 Pa of absolute pressure with a capacity of approximately 10 m<sup>3</sup>/h. If such a pump is available, one evacuation will normally suffice to achieve an absolute pressure of 150 Pa. If there is no such vacuum pump available, or whenever the circuit has remained open for long periods of time, you are strongly recommended to adopt the triple evacuation method. This method is also recommended when there is a presence of humidity within the circuit. The vacuum pump should be connected to the inlets.

The procedure to be carried out is as follows:

- Evacuate the circuit until you reach an absolute pressure of at least 350 Pa: at this point inject nitrogen into the circuit until you reach a relative pressure of about 1 bar.
- Repeat the step described above.
- Carry out the step described above for the third time, but in this case attempting to reach the hardest vacuum possible.

Using this procedure you can easily remove up to 99% of pollutants.

### 11.8 Recharging with refrigerant R410A

- Connect the tank of refrigerant gas to the male 1/4 SAE inlet situated on the liquid line after discharging a little gas to eliminate air in the connection pipe.
- **Fill with refrigerant in liquid form** until you reach 75% of the total charge. For monobloc unit (water cooled), the correct refrigerant charge is shown in silver plate. For split units (air cooled) check the "Piping design criteria" attached to the unit documentation.
- Then connect to the inlet on the pipe between the thermostatic valve and evaporator and complete the charging process with the refrigerant **in liquid form** until no more bubbles can be seen on the liquid level indicator and the operating parameters specified in section 7.4 have been reached (see piping design criteria).



**These units are designed for the exclusive use of R410A refrigerant and should not be charge with different refrigerants without the written permission of the manufacturer.**

### 11.9 Environmental protection

The law implementing the regulations (reg. EEC 2037/00) which govern the use of ozone-depleting substances and greenhouse gases bans the dispersal of refrigerant gases in the environment and requires whoever is in their possession to recover them and, at the end of their useful life, either to return them to the dealer or take them to a suitable waste disposal facility. The refrigerant HFC R410A is not harmful to the ozone layer but is included among the substances responsible for the greenhouse effect and thus falls within the scope of the aforesaid regulations.



**Therefore, special care should be taken when carrying out maintenance work to minimize refrigerant leaks.**

## 12 Troubleshooting

On the next pages you will find a list of the most common reasons that may cause the package unit to fail or any malfunction. This causes are broken down according to easily identifiable symptoms.

FAULT	POSSIBLE CAUSES	CORRECTIVE ACTIONS
<b>The unit does not start</b>	No power supply.	Check if power is being supplied both to the primary and auxiliary circuits.
	The electronic card is cut off from the power supply.	Check the fuses.
	Alarms have been released.	Check whether any alarms are signalled on the microprocessor control panel, eliminate the causes and restart the unit.
	The phase sequence is wrong.	Invert two phases in the primary power line after disconnecting them upstream from the unit.
<b>The compressor is noisy</b>	The compressor is rotating in the wrong direction.	Check the phase sequence relay. Invert the phases on the terminal board after disconnecting the unit and contact the manufacturer.
<b>Presence of abnormally high pressure</b>	Insufficient airflow through the condenser.	Check for the presence of obstructions in the condenser section ventilation circuit.
		Check whether the condenser coil surface is obstructed.
		Check the condensation control device (optional).
	Presence of air in the refrigerant circuit, as revealed by the presence of bubbles in the flow indicator also with sub-cooling values exceeding 5 °C.	Drain and pressurise the circuit and check for leaks. Evacuate slowly (for more than 3 hours) until reaching a pressure of 0.1 Pa and then recharge in the liquid phase.
	Unit overcharged, as revealed by a Sub-cooling of more than 8 °C.	Drain the circuit.
<b>Low condensation pressure</b>	Thermostatic valve and/or filter obstructed. These symptoms may also occur in the presence of an abnormally low pressure.	Check the temperatures upstream and downstream from the valve and filter and replace them if necessary.
	Transducer fault.	Replace the trasducer.
<b>Low evaporation pressure</b>	Wrong sentting of the condensation control device	Check the efficiency of the condensation control device (optional).
	Malfunctioning of thermostatic valve.	Warming the bulb with your hand, check whether the valve opens and adjust it if necessary. If it does not respond, replace it.
	Filter dryer clogged.	Pressure drops upstream and downstream from the filter should not exceed 2°C. If they do, replace the filter.
	Low condensation temperature.	Check the efficiency of the condensation control device (where present).
<b>The compressor does not start</b>	Low level of refrigerant.	Check the refrigerant level by measuring the degree of Sub-cooling; if it is below 2°C replenish the charge.
	The internal thermal protection device has tripped.	In the case of compressors equipped with a protection module, check the thermal contact. Identify the causes after restarting.
	The circuit breakers or line fuses have been tripped by a short circuit.	Pinpoint the cause by measuring the resistance of the individual windings and the insulation from the casing before restoring power.
	One of the HP or LP pressure switches has tripped.	Check on the microprocessor, eliminate the causes.
<b>Air in the hydraulic circuit</b>	The phases have been inverted in the distribution compartment.	Check the phase sequence relay (only DX).
	During external connections.	Open the valve positioned on the right side over the top of the coil.
<b>Water out from the unit</b>	The drain pan hole is closed.	Open the front panels, remove the sheet metal just below the e-panel (down flow units) and clean it.
	The siphon is missing.	Check for the presence and provide for a new one.
	The air flow is too high.	Reduce the fan speed up to reaching the nominal air flow.
	Unit is not prfectly levl	Place correctly the unit.



**You should be extremely careful when attempting to implement any of the possible remedies suggested: overconfidence can result in injuries, even serious ones, to inexperienced individuals. Therefore, once the cause has been identified, you are advised to contact the manufacturer or a qualified technician for help.**







## SALES OFFICES

### BELGIUM AND LUXEMBOURG

+32 3 633 3045

### FRANCE

+33 1 64 76 23 23

### GERMANIE

+49 (0) 211 950 79 60

### ITALY

+39 02 495 26 200

### NETHERLANDS

+31 332 471 800

### POLAND

+48 22 58 48 610

### PORTUGAL

+351 229 066 050

### RUSSIA

+7 495 626 56 53

### SPAIN

+34 915 401 810

### UKRAINE

+38 044 585 59 10

### UNITED KINGDOM AND IRELAND

+44 1604 669 100

### OTHER COUNTRIES

### LENNOX DISTRIBUTION

+33 4 72 23 20 20



Due to LENNOX EMEA ongoing commitment to quality, the specifications, ratings and dimensions are subject to change without notice and without incurring liability. Improper installation, adjustment, alteration, service or maintenance can cause property damage or personal injury. Installation and service must be performed by a qualified installer and servicing agency.

**INNOVA ENERGY-  
IOM-2205-E**

